



## KOORDINAATTILUETTELO

Koordinaattijärjestelmä ETRS-GK25

N:O	X	Y
1	6721363.258	25493771.169
2	6721358.945	25493767.157
3	6721357.642	25493750.568
4	6721354.569	25493730.247
5	6721352.696	25493717.857
6	6721355.807	25493712.362
7	6721385.861	25493699.853
8	6721387.832	25493699.428
9	6721405.600	25493695.595
10	6721409.196	25493694.981
11	6721429.734	25493691.476
12	6721432.084	25493691.075
13	6721459.829	25493689.241
14	6721465.623	25493694.842
15	6721464.993	25493714.371
16	6721464.239	25493737.780
17	6721464.464	25493740.503
18	6721466.225	25493761.793
19	6721460.740	25493768.267
20	6721435.927	25493770.319
21	6721421.477	25493771.515
22	6721415.205	25493771.477
23	6721393.881	25493771.351
24	6721391.907	25493747.877
25	6721390.896	25493735.853
26	6721390.189	25493727.449
27	6721412.275	25493734.174
28	6721433.785	25493743.040
29	6721432.961	25493732.549
30	6721431.749	25493717.120

## TONTTIEN MUODOSTUMINEN

Tontti	P-ala	Osap-ala	Kiinteistö
028 2751 0001	753	753	403 0006 0127
028 2751 0002	719	719	403 0006 0127
028 2751 0003	811	811	403 0006 0127
028 2751 0004	819	819	403 0006 0127
028 2751 0005	835	835	403 0006 0127
028 2751 0006	875	875	403 0006 0127
028 2751 0007	830	830	403 0006 0127
028 2751 0008	826	826	403 0006 0127
028 2751 0009	785	785	403 0006 0127
028 2751 0010	780	780	403 0006 0127